





DEURSTATION S-140V



Max. 50 meter

| N-waarde | Huisnummer | Eindweerstand |
|----------|------------|---------------|
| 1        | 25         |               |
| 2        | 27         |               |
| 3        | 29         |               |
| 4        | 31         |               |
| 5        | 33         |               |
| 6        | 35         |               |
| 7        | 37         |               |
| 8        | 39         |               |
| 9        | 41         |               |
| 10       | 43         |               |
| 11       | 45         |               |
| 12       | 47         |               |
| 13       | 49         |               |
| 14       | 51         |               |
| 15       | 53         |               |
| 16       | 55         |               |
| 17       | 57         |               |
| 18       | 59         |               |
| 19       | 61         |               |
| 20       | 63         |               |
| 21       | 65         |               |
| 22       | 67         |               |
| 23       | 69         |               |
| 24       | 71         |               |
| 25       | 73         |               |
| 26       | 75         |               |
| 27       | 77         |               |
| 28       | 79         |               |
| 29       | 81         |               |
| 30       | 83         |               |
| 31       | 85         | X             |
| 32       | 87         | X             |
| 33       | 89         | X             |
| 34       | 91         | X             |
| 35       | 93         | X             |
| 36       | 95         | X             |
| 37       | 97         | X             |
| 38       | 99         | X             |
| 39       | 101        | X             |
| 40       | 103        | X             |

nelec

INTERCOM MADE EASY