


VideoVerdelers




De aders moeten echt OP de klemmen doorgelust worden!

M-50



De aders moeten echt OP de connector doorgelust worden!



van E-67 pagina 1

N-waarde	Huisnummer	Eindweerstand
1	61	
2	62	
3	63	
4	64	
5	65	
6	66	
7	67	
8	68	
9	69	
10	70	
11	71	
12	72	
13	73	
14	74	
15	75	
16	76	
17	77	
18	78	
19	79	
20	80	
21	81	
22	82	
23	83	
24	84	
25	85	
26	86	
27	87	
28	88	
29	89	
30	90	
31	91	
32	92	
33	93	X
34	94	X
35	95	X
36	96	X
37	97	X
38	98	X
39	99	X
40	100	X

nelec
 INTERCOM MADE EASY