






Adressen in buitenpost P=1

Adressen in buitenpost P=0

Haal de spanning van het systeem als je een digitizer monteert of demonteert



Haal de spanning van het systeem als je een digitizer monteert of demonteert



N-Waarde	Huisnummer	Switch-ON
1	125	X
2	127	X
3	129	X
4	131	X
5	133	X
6	135	X
7	137	X
8	139	X
9	141	X
10	143	X
11	145	X
12	147	X
13	149	X
14	151	X
15	153	X
16	155	X
17	157	X
18	159	X
19	161	X
20	163	X
21	165	X
22	167	X
23	169	X
24	171	X
25	173	X
26	175	X
27	177	X
28	179	X
29	181	X
30	183	X
31	185	X
32	187	X
33	189	X
34	191	X
35	193	X
36	195	X
37	197	X
38	199	X
39	201	X
40	203	X
41	205	X
42	207	X
43	209	X
44	211	X
45	213	X
46	215	X
47	217	X
48	219	X
49	221	X
50	223	X