




Met de bewakingsfunctie op de videofoons kan
enkel de lokale buitenpost opgeroepen worden.
Buitenpost P=0 is enkel te zien tijdens een oproep.

Gebouw Links

N+100

N-Waarde	P-Waarde	Huisnummer	Switch-ON
1	2	2	
2	2	4	
3	2	6	
4	2	8	
5	2	10	
6	2	12	
7	2	14	
8	2	16	
9	2	18	
10	2	20	
11	2	22	
12	2	24	
13	2	26	
14	2	28	
15	2	30	
16	2	32	
17	2	34	
18	2	36	
19	2	38	
20	2	40	X
21	2	42	
22	2	44	X
23	2	46	
24	2	48	X
25	2	50	X
26	2	52	X
27	2	54	X

Gebouw Rechts

N+200

N-Waarde	P-Waarde	Huisnummer	Switch-ON
1	4	56	
2	4	58	
3	4	60	
4	4	62	
5	4	64	
6	4	66	
7	4	68	
8	4	70	
9	4	72	
10	4	74	
11	4	76	
12	4	78	
13	4	80	
14	4	82	
15	4	84	
16	4	86	
17	4	88	
18	4	90	
19	4	92	
20	4	94	X
21	4	96	
22	4	98	X
23	4	100	
24	4	102	X
25	4	104	X
26	4	106	X
27	4	108	X