




N-waarde	Huisnummer	Eindweerstand
1	1	
2	3	
3	5	
4	7	
5	9	
6	11	
7	13	
8	15	
9	17	
10	19	
11	21	
12	23	
13	25	
14	27	
15	29	
16	31	
17	33	
18	35	
19	37	
20	39	
21	41	
22	43	
23	45	
24	47	
25	49	
26	51	
27	53	
28	55	
29	57	X
30	59	X
31	61	X
32	63	X
33	65	X
34	67	X
35	69	X
36	71	X
37	73	X
38	75	X

nelec
INTERCOM MADE EASY