






Haal de spanning van het systeem als je een digitizer monteert of demonteert



N-Waarde	Huisnummer	Switch-ON	Videofoon	1-2 ON
1	1172	X	M-50B	
2	1174	X	M-50W ifi	X
3	1176	X	M-50B	
4	1178	X	M-50B	
5	1180	X	M-50W ifi	X
6	1182	X	M-50B	
7	1184	X	M-50W ifi	X
8	1186	X	M-50B	
9	1188	X	M-50B	
10	1190	X	M-50B	
11	1192	X	M-50W ifi	X
12	1194	X	M-50B	
13	1196	X	M-50W ifi	X
14	1198	X	M-50B	
15	1200		M-50W ifi	X
16	1202	X	M-50B	
17	1204	X	M-50W ifi	X
18	1206	X	M-50B	
19	1208	X	M-50B	
20	1210	X	M-50B	
21	1212	X	M-50B	
22	1214	X	M-50W ifi	X
23	1216	X	M-50W ifi	X
24	1218	X	M-50B	
25	1220	X	M-50B	
26	1222	X	M-50B	
27	1224	X	M-50B	
28	1226	X	M-50B	
29	1228	X	M-50B	
30	1230	X	M-50W ifi	X
31	1232	X	M-50B	
32	1234	X	M-50B	
33	1236		M-50B	
34	1238	X	M-50B	
35	1240	X	M-50B	
36	1242	X	M-50B	
37	1244	X	M-50B	
38	1246	X	M-50B	
39	1248	X	M-50B	
40	1250	X	M-50B	
41	1252	X	M-50B	
42	1254	X	M-50B	
43	1256	X	M-50B	
44	1258	X	M-50B	