




N-waarde	Huisnummer	Eindweerstand
1	14A	
2	14B	
3	14C	
4	14D	
5	14E	
6	14F	
7	14G	
8	14H	
9	14J	
10	14K	
11	14L	
12	14M	
13	14N	X
14	14P	X
15	14Q	X
16	14R	X
17	14S	X
18	14T	X
19	14U	X
20	16A	
21	16B	
22	16C	
23	16D	
24	16E	
25	16F	
26	16G	
27	16H	
28	16J	
29	16K	X
30	16L	X
31	16M	X
32	16N	X
33	16P	X

nelec

INTERCOM MADE EASY